

# Code Notches for KODAK Sheet Films



Kodak sheet films have a notch or a group of notches on one edge of each sheet. These notches serve two purposes: They indicate the film type and help you to identify the emulsion side quickly. When the notch is at the top right edge of the sheet, the emulsion side faces you.

## KODAK Color Negative and Print Films for Process C-41

PORTRA 160NC



PORTRA 160VC



PORTRA 400NC



PORTRA 100T



## KODAK Color Transparency Films for Process E-6

EKTACHROME 64  
Professional / EPR



EKTACHROME 100  
Professional / EPN



EKTACHROME 100 Plus  
Professional / EPP



EKTACHROME 64T  
Professional / EPY



EKTACHROME E100G



EKTACHROME E100VS



EKTACHROME Duplicating  
EDUPE



EKTACHROME Electronic  
Output 100



EKTACHROME Electronic  
Output 64T



# Code Notches for KODAK Sheet Films

---

## KODAK Black-and-White Films

KODALITH Ortho 2556,  
Type 3



(No Notch)

Technical Pan / TP



(Universal Notch)

T-MAX 100 / 100TMX



T-MAX 400 / 400TMY



TRI-X 320 / 320TXP



## Universal Code Notches

These code notches are for low-volume and special-order (SO) films.

Films for  
Black-and-White  
Processes



Films for Process E-6



Films for Process C-41



Digital & Film Imaging Systems  
**EASTMAN KODAK COMPANY • ROCHESTER, NY 14650**

